

<https://www.techfinder.in>



<https://www.techfinder.in>

Glasses Camera User Manual

- Tf Card
- Video
- Take Pictures
- Pc Camera Function



Video



Take pictures



TF Card




PC camera function

<https://www.techfinder.in>



I. Structure



II. Operation instructions

1. Power on

In shutdown state, long press the power button, the red and blue lights become on, the red light will be off after the device initialization, the blue light will always be bright, the device turns into standby mode. (If not enter into other function within one minute, the device will be shutdown automatically, without memory card, the double exchange lights flash 3 times, then power off automatically).

2. Photo

In standby mode, short-time press the power button to start taking pictures, the blue light is off, then lights on, and save a *.JPG format image files.

<https://www.techfinder.in>

Note: Please take photos in the environment with full illumination, the lens is not covered by shelter, and keep the distance with the subject more than 50 cm. Then, the photos are in correct directions, natural colors, clear pictures and stable images.

3. Video

In stand-by state, long-time press the video button for about 2 seconds, the blue light flashes 3 times then light off, start videoing. In videoing, short-time press the video button, the blue light is on, stop videoing, a file in *.AVI format is saved. For guaranty the size and safety of the taken videos, the system saves the videos once every 10 minutes automatically, and taking the video continuously.

4. Power off

<https://www.techfinder.in>

In stand-by state, long-time press the power-on button for 3 seconds, the blue light is off, meanwhile, the red light flashes 3 times then becomes off, indicating the shutdown.

5. Low-voltage

<https://www.techfinder.in>

When the product detects the low voltage of battery in working, the light flashes twice, then shut down automatically. The files being taken will be saved before shutdown.

6. Reset

When the product stops response from misuse or other unknown reasons and can't connect with the computer, please Use slim pole to press the Reset button .and then finish one reset operation.the product is in shutdown,

<https://www.techfinder.in>

7. Charge

Charging the product by connecting the product with the computer or by AC adapter, the read light is flashing in charging, the blue light is on in full charging.

<https://www.techfinder.in>

8. Time set

the video recorder provides the function to display the video record time in video file, you can set the time and the time display or not according to actual needs; the time display format: "Year-Month-Day Hours:

Minutes: Seconds Y" , setup times are as follows:

a. Turn off the camera—>to connect the computer—> open the removable disk—> click the right mouse button on blank space of the root directory of the device —>move the cursor on "New" option of the pop-up menu —> select "Text Document"—> named "time" to the text document, need to pay attention to its extension name is ". txt" —> completion of setting up time file; you can set up in accordance with the above steps on your desktop, other disk partition, under the other folder and then copy to a removable disk root directory.

b. Open the "time" text document, input the time settings string, the string is composed of "Year-Month-Day <https://www.techfinder.in>

Hours.Minutes.Seconds Y" ,set-up times are as follows:

With time shows: 2015-03-01 23:59:59 Y

Without time shows: 2015-03-01 23:59:59 N

III. Tech parameters:

Item	Parameter
Video format	AVI
Video encoding	M-JPEG
Video resolution	1920*1080P or 1280*720P VGA
Video frame rate	30fps±1fps
Media playing software	Attached software in the operating system, or the mainstream video playing software
Picture format	JPG
Picture pixel	12MP https://www.techfinder.in
Image ratio	4:3
Compatible O/S	Windows me/2000/XP/2003/vista; Mac OS 10.4; Linux;
charging voltage	DC-5V
Charging time	About 1.5 hours
Interface	Mini 5 Pin USB
Storage	Micro SD(TF) card, up to 32GB
Battery	high-capacity lithium polymer

<https://www.techfinder.in>

IV. Attention:

a.Application: Please abide by the relevant regulations and laws in your country. The product is forbidden for any illegal purposes. The user is fully responsible for the illegal purposes.

b.Battery: The working time becomes shorter with increase of the use time. Please charge the battery fully before using when the product is in long-time storage. <https://www.techfinder.in>

c. **File safety:** The product is not a professional storage device, not guarantee the completeness and safety of the stored files. Please back up your important files on the computer or other storage devices timely.
<https://www.techfinder.in>

d. **Video quality:** The product is not a professional video device, not guarantee the effect of the taken videos reaches your respect.

e. **Working temperature:** 0~40 °C <https://www.techfinder.in>

f. **Working humidity:** 20%—80%, please avoid the humid working environment, the product is not waterproof.

g. **Shoot illumination:** Please shoot in the environment with enough illumination, don't make the lens face the sun, the strong light source etc. directly, avoiding the harm to the optical components.

h. **Cleaning requirements:** Please don't use the product in the high dusty environment, against the dust to the camera lens and other components, that effects the video quality. Please clean the lens with lens paper or glass cloth gently, keep clean.
<https://www.techfinder.in>

i. **Others:** The product belongs to the precise electronics. Please avoid the strong impact, shock. Please don't use the product in strong magnetic field, or in strong electric field.

j. **Complement:** The other unknown matters, please contact with your local dealers.
<https://www.techfinder.in>